How to change the source played on my Classic Stereo Mini?

Customer Support - 2025-10-09 - Classic Stereo Mini

You would like to change the source that is playing on your Classic Stereo Mini?

The available sources on the Classic Stereo Mini are **DAB+**, **FM**, **Bluetooth**, **USB**, **CD**, **Aux In**.

1. To choose a source for playback, simply tap on the "**Source**" button of your Classic Stereo Mini to open the selection window.

2. Pressing the "**Source**" button repeatedly or turning the "**Volume/Select**" dial will cycle through the available sources.

3. To confirm your selection, press the "**Volume/Select**" dial.

The source will also change to the highlighted automatically after 2 seconds, if no other button is pressed.

Your remote control also offers **direct access buttons** for the different sources available.