How to change FM stations on a Classic H4i/Classic C-D6i?

Customer Support - 2026-05-05 - Classic H4i

You would like to save and change your FM Stations on your Classic H4i/Classic C-D6i?

When you switch to FM mode for the first time, a station scan is performed first. All stations received are now saved in the '**Station list**'.

This process can take a few moments as it records every station. You do not need to do anything.

1. To change the FM station, turn the '**Select**' dial one notch to open the '**Station list**'.
2. Turn the '**Select**' knob again to select a station.
3. When you have found the desired station, press the '**Select**' dial to call up the station.

To perform a new scan for all FM stations

1. Press the '**Home/Back**' button.
2. Select '**FM Setup**' and confirm by pressing the '**Select**' dial.
3. Choose '**FM full scan**' and again confirm your selection.

Your radio will then delete all stored FM stations and automatically start scanning for all available stations.