How do I set an alarm?

Customer Support - 2026-10-30 - Evoke Home II

Would you like to set an alarm on your Evoke Home II?

Setting an alarm on your Evoke Home II is very simple.

Let’s go through the steps together using an example.

To set an alarm,

1. first press the ‘Source’ button and turn the dial to ‘Alarm’.
2. Press the dial to open the settings.
3. Select ‘Alarm 1’ and press the dial to confirm.
4. Select ‘Turn on’ and confirm by pressing the dial.

1. The settings will open.
2. Now set the ‘Time’ you want to be woken up by pressing the dial to select the hours, then pressing the dial again to move to the minutes.
3. Turn the dial again to set the minutes, and press the dial to confirm your time settings.
4. The ‘Sound’ option allows you to choose between Alarm Tone, My Favourites, DAB and FM.
5. Select your preferred source and press the dial to confirm.
6. Under ‘Repeat’, you can specify on which days you would like to be woken up.
7. You can also adjust the alarm volume and duration to suit your individual needs.

Active alarms are indicated by the relevant icons.

When the alarm goes off:

You can snooze the alarm for 9 minutes by pressing the rotary control or the Select button on your remote control.

Press Home button to go to the playback screen

Press any other key to switch off the alarm.