How to save/recall presets on a Classic Stereo Mini?

Customer Support - 2025-10-09 - Classic Stereo Mini

You would like to save a preset or recall a preset on your Classic Stereo Mini?

The Classic Stereo Mini allows you to save up to **40** presets for **DAB+** and **FM** radio.

1. To store a station to the preset list, long press the "**Presets**" button until the "**Save to Preset**" list opens.

2. Turn the "**Volume/Select**" dial to choose the position within the list (**1-40**) and press the "**Volume/Select**" dial to confirm. The station listened to is now saved on the chosen preset.

3. This can also be done using your remote control. This also offers **6 Quick Access** buttons, allowing you to save and recall presets 1-6.

4. To recall a preset, short press the "**Presets**" button (also available on your remote control), select the station you would like to listen to, and confirm by pressing the "**Volume/Select**" dial (or "**Select**" button on the remote).