Wie lade ich meinen Classic Aura Lautsprecher auf und überprüfe den Akkustatus?

Customer Support - 2026-05-05 - Classic Aura

Du möchtest deinen Classic Aura aufladen und den Akkustatus überprüfen?

1. Für den Classic Aura brauchst du ein USB-C-Ladegerät mit 5 bis 30 Watt.

30 Watt sind nötig, um das Gerät schnellstmöglich aufzuladen und während des Ladevorgangs die maximale Lautstärke zu erreichen.




1. Schließ den Lautsprecher an das USB-C-Ladegerät an.


Das Eco-Symbol (Akku) blinkt während des Ladevorgangs. 



1. Sobald der Akku zu 100 % aufgeladen ist, hört das Eco-Symbol (Akku) auf zu blinken.

Du kannst den Ladezustand auch während des Hörens überprüfen, indem du die Eco-Taste 2 Sekunden lang drückst.

Die 4 LEDs über dem Lautstärkeregler zeigen den aktuellen Akkustatus an.

Battery level		LED Behavior				Illustration
From	To	LED1	LED2	LED3	LED4	
75%	100%	high	high	high	blink	
45%	75%	high	high	blink	off	
25%	45%	high	blink	off	off	
5%	25%	high	off	off	off	
0%	5%	blink	off	off	off	



Battery level		LED Behavior				Illustration
From	To	LED1	LED2	LED3	LED4	
95%	100%	on	on	on	on	
75%	95%	on	on	on	pulse	
45%	75%	on	on	pulse	off	
25%	45%	on	pulse	off	off	
0%	25%	pulse	off	off	off	

