Classic Stereo Mini - Quick Help

Customer Support - 2025-11-12 - Classic Stereo Mini

Our most important tips on how to use your Classic Stereo Mini

1. **Before operating the product**, always consult the **Classic Stereo Mini User Guide.**

You can also refer to the Quick Start Guide for the Classic Stereo Mini available in our **Download Center**

To get a first impression of how to use your new Pure audio system, also **take a look at this video**.

1. **Before we start**, we state the obvious.

Please make sure you have properly connected your speakers to the Classic Stereo Mini before the device is connected to a power source.

Make sure that the antenna is fully extended and all plastic covers are removed.

1. **Switching Classic Stereo Mini on/off**

Pressing the Standby button will boot your Classic Stereo Mini to the last source listened. When you use Classic Stereo Mini for the first time, the unit will perform a DAB scan.

1. **Scanning and selecting DAB+ or FM Stations**

We have two separate articles on these topics that you can select by clicking on the highlighted words. DAB+ FM Stations

1. **Saving or recalling a preset**

The Classic Stereo Mini offers two methods to save presets. These can either be saved to one of the 6 quick preset buttons on the remote control or added to the preset list.

Pressing one of the quick preset buttons until "Preset stored" appears, will save the station currently listened to. Short press the preset button to recall it. More details can be found **here**.

1. **Changing the source**

This is kept straight forward. Pressing the "Source" button will open the source window. If you want to know more about the source options, read this article **here**.

1. **Pairing a Bluetooth device**

Press the BT button and the Classic Stereo Mini will enter pairing mode. More detailed instructions on how to find your Classic Stereo Mini on the device you want to pair and more on pairing with BT can be found **here**.

1. **Setting an alarm**

The Classic Stereo Mini has 2 individual alarms you can set. We have created a detailed **step-by-step help article** to explain the details.

1. **Adjusting the display brightness in Standby and On mode**

Classic Stereo Mini gives you various customization options to adjust the display brightness. Each of these functions is described in the respective help article **linked here**.

1. **Selecting the equalizer modes**

The different modes can be reached by pressing the EQ button on the remote control. Find more **details here**.