

FAQs > Elan Series - DAB+ Radios > How can I change the source played on my Elan One²?

How can I change the source played on my Elan One²? Customer Support - 2024-12-09 - Elan Series - DAB+ Radios

You would like to change the source that is playing on your Elan One²?

The available sources on the Elan One² are **DAB+**, **FM**, and **Bluetooth**.

- To choose a source for playback, simply tap on the "Source" button and select it by turning the "Volume/Select" dial.
- 2. Pressing the "**Source**" button repeatedly will also cycle through the available sources.
- 3. To confirm your selection, press the "Volume/Select" dial.

The source will also change to the highlighted automatically after 2 seconds, if no other button is pressed.