



FAQs > Evoke Series - Modern Music Systems > Evoke Play > How can I change the source played on my Evoke Spot/Play?

How can I change the source played on my Evoke Spot/Play?

Customer Support - 2024-11-14 - Evoke Play

You would like to change the source that is playing on your Evoke Spot/Play?

The available sources on the Evoke Spot/Play are DAB+, FM, Internet Radio, Spotify, Podcasts and Bluetooth Audio.

1. To choose a source for playback, simply tap on the “**Source**” button of your Evoke Spot/Play to open the selection window.
2. Pressing the “**Source**” button repeatedly or navigating with the arrow keys will cycle through the available sources.
3. To confirm your selection, press the “**Home/select**” button.

The source will also change to the highlighted automatically after 2 seconds, if no other button is pressed.