How do I check the status of my battery [Woodland, Woodland Mini, Woodland Glow]

INSIDE / AQIPA - 2025-07-31 - Woodland

Woodland

The battery indicator is located in the upper right hand corner of the display. When turning the speaker on, the display will lite up for a few seconds.

During operation, a short tap on the Power button will again illuminate the display.



Woodland Mini

The battery indicator is located in the upper right hand corner of the display. When turning the speaker on, the display will lite up for a few seconds.

During operation, a short tap on the Power button will again illuminate the display.



Woodland Glow

The battery status of the Woodland Glow is displayed by 4 LEDs. When turning the speaker on, the LEDs will lite up for a few seconds.

During operation, a short tap on any of the buttons will recall the status.

