



[FAQs](#) > [Classic Series - DAB+ and Music Systems](#) > [Classic H4i](#) > [How to pair a Bluetooth device with the Classic H4i/Classic C-D6i?](#)

How to pair a Bluetooth device with the Classic H4i/Classic C-D6i?

Customer Support - 2025-07-29 - [Classic H4i](#)

Would you like to pair your phone or another Bluetooth device to your Classic H4i/Classic C-D6i?

When you switch to Bluetooth mode for the first time by selecting Bluetooth as the source, pairing mode is automatically activated.

You just need to go to the Bluetooth settings of your device, find the Classic H4i/Classic C-D6i in the list and select it for pairing.

The next time you enter Bluetooth mode, the Classic H4i/Classic C-D6i will automatically try to reconnect to the last connected device.

You are now connected via Bluetooth and can enjoy your music wirelessly with the Classic H4i/Classic C-D6i.

To pair a new device or to pair/unpair a device, press and hold the '**Bluetooth/Pair**' button until '**Pair**' is displayed.

If no device is currently paired, the Classic H4i/Classic C-D6i will automatically switch to pairing mode.