



[FAQs](#) > [Classic Series - DAB+ and Music Systems](#) > [Classic H6](#) > [How to change FM stations on a Classic H6?](#)

## How to change FM stations on a Classic H6?

Customer Support - 2025-10-10 - [Classic H6](#)

### Want to save and change your FM stations on your Classic H6?

When you switch to FM mode for the first time, your Classic H6 will start searching for stations.

The radio will now search for all available FM stations and save them to the presets (**max. 40**).

This process may take a few moments as it scans each station. You do not need to do anything.

1. To change the FM station later, briefly press the '**Favourites list**' button on the radio or on the remote control while in FM mode.
2. This will open the '**Recall presets**' list.
3. Turn the '**Select**' knob (up/down buttons on the remote control) to select a station.
4. When you have found the desired station, press the rotary knob to recall the station.

If you are looking for a specific FM station or want to fine-tune your listening experience, turn the '**Select**' knob to manually search through the FM frequencies.

To perform a new search for all FM stations, press the '**Home/Back**' button and select '**Station Search**' from the main menu.

Your radio will then delete all stored FM stations and automatically start searching for all available stations.