



[FAQs](#) > [Classic Series - DAB+ and Music Systems](#) > [Classic Active](#) > [How to change the EQ settings on a Classic Active?](#)

How to change the EQ settings on a Classic Active?

Customer Support - 2026-03-24 - [Classic Active](#)

You would like to change the EQ audio settings on your Classic Active?

1. The different EQ settings on the Classic Active can be selected by pressing the corresponding buttons on your remote control.

2. You can choose between

Dynamic - Deep bass extension - dynamic vocals and instruments

Comfort - Easy listening all day

Neutral - Sound as close to the source material

1. Selecting **Custom** will enable you to adjust the EQ settings for the **Bass**, **Mid** and **High** frequencies individually.

An additional **Night Mode** will reduce the dynamic in evening hours.