How to change the EQ settings on a Classic Stereo Mini?

Customer Support - 2025-10-10 - Classic Stereo Mini

You would like to change the EQ audio settings on your Classic Stereo Mini?

1. To reach the EQ settings on the Classic Stereo Mini, press the "**Home**" button on the main unit, or your remote.
2. Select "**Equaliser**" in the "**System Settings**".
3. Confirm by pressing the "**Volume/Select**" dial/button.
4. You can now select from **Dynamic**, **Comfort**, **Neutral**, **Night**, and the option to personalise your sound using the "**Custom EQ Setting**".
5. Entering the "**Custom EQ Setting**" allows you to manually set Bass and Treble.

You can also reach the EQ using the "**EQ**" button on your remote control.

Repeatedly pressing the "**EQ**" button lets you toggle through the different modes.

The different modes are:

Dynamic - Deep bass extension - dynamic vocals and instruments

Comfort - Easy listening all day

Neutral - Sound as close to the source material

Night - Prevent sudden increases in Bass and Treble

Custom EQ - Define your own character with Bass and Treble controls