



[FAQs](#) > [Elan Series - DAB+ Radios](#) > [Elan Move](#) > [How to change the source played on my Elan Move?](#)

How to change the source played on my Elan Move?

Customer Support - 2026-03-27 - [Elan Move](#)

You would like to change the source that is playing on your Elan Move?

The available sources on the Elan Move are **DAB**, **FM** and **Bluetooth**.

1. To choose a source for playback, simply tap on the "**Source**" button of your Elan Move.
2. Pressing the "**Source**" button repeatedly will cycle through the available sources.
3. To confirm your selection, press the "**Select**" button.

The source will also change to the highlighted automatically after 2 seconds, if no other button is pressed.