How to change the source playing on the Classic H6?

Customer Support - 2026-05-05 - Classic H6

Want to change the source playing on your Classic H6?

The available sources are **DAB**, **FM**, **Bluetooth**, **Aux In** and **USB**.

1. To select a source for playback, simply tap the '**Source**' button on your Classic H6 to open the selection window.
2. Press the '**Source**' button repeatedly or turn the "**Select**" wheel to cycle through the available sources.
3. To confirm your selection, press the '**Select**' knob.