



[FAQs](#) > [Classic Series - DAB+ and Music Systems](#) > [Classic Aura](#) > [How to charge my Classic Aura speaker and check the battery status?](#)

How to charge my Classic Aura speaker and check the battery status?

Customer Support - 2026-05-05 - [Classic Aura](#)

You wish to charge your Classic Aura and check the battery status?

1. Classic Aura requires a USB-C charger between 5W - 30W.

30W is required for optimal charging speed and allowing for maximum volume whilst charging.

1. Connect the speaker to the USB-C charger.

The Eco (Battery) icon will blink whilst charging.



1. Once 100% charged the Eco (Battery) icon will stop blinking.

You can also check the charging state while listening by pressing the Eco button for 2sec.

The 4 LEDs above the volume dial will illuminate the current battery status.



Battery Status Indicator - In Use

Battery level		LED Behavior				Illustration
From	To	LED1	LED2	LED3	LED4	
75%	100%	high	high	high	blink	
45%	75%	high	high	blink	off	
25%	45%	high	blink	off	off	
5%	25%	high	off	off	off	
0%	5%	blink	off	off	off	

High
 Low
 Pulse
 Blink
 Off

Battery Status Indicator - Charging

Battery level		LED Behavior				Illustration
From	To	LED1	LED2	LED3	LED4	
95%	100%	on	on	on	on	
75%	95%	on	on	on	pulse	
45%	75%	on	on	pulse	off	
25%	45%	on	pulse	off	off	
0%	25%	pulse	off	off	off	

High
 Low
 Pulse
 Blink
 Off