



[FAQs](#) > [Classic Series - DAB+ and Music Systems](#) > [Classic Active](#) > [How to pair a Bluetooth device with a Classic Active?](#)

## How to pair a Bluetooth device with a Classic Active?

Customer Support - 2026-03-24 - [Classic Active](#)

### Would you like to pair your phone or another Bluetooth device with your Classic Active?

When you switch to Bluetooth mode for the first time by selecting Bluetooth as a source, the Classic Active will automatically enter pairing mode.

All you need to do is go to the Bluetooth settings on your device, find Classic Active in the list, and select it to pair.

The next time you enter Bluetooth mode, Classic Active will automatically try to reconnect to the last connected device.

You're now connected via Bluetooth and ready to enjoy your music wirelessly with Classic Active.

To pair a new device or if you need to re-pair/unpair a device, press the "**Bluetooth**" button on the Classic Active or your remote until "**Pairing**" is displayed.

If no device is currently paired, Classic Active will automatically enter pairing mode.