



FAQs > Moment Series- Sleep Companions > Moment > How to save or recall presets [Moment, Moment Charge]?

How to save or recall presets [Moment, Moment Charge]?

INSIDE / AQIPA - 2025-01-27 - Moment

You would like to save a preset or recall a preset on your Moment or Moment Charge?

Your Moment offers the option to save up to 10 presets for quick access. These can be a combination of DAB, FM stations and your preferred Sounds.

1. To save your selection as a preset, simply hold the "Preset" button pressed while listening to the station/sound until "Saved" appears on the display.
2. To recall a preset, simply tap the "Presets" button to access the list of your saved presets. Scroll to the desired preset by turning the "Select" dial and confirm your selection by pressing the dial.
3. To delete a preset no longer required, first select the preset for playback. Then hold the "Preset" button pressed until "Removed" is displayed.