



FAQs > Classic Series - DAB+ and Music Systems > Classic Mini > How to scan and select DAB stations on a Classic Mini?

How to scan and select DAB stations on a Classic Mini?

Customer Support - 2025-01-27 - Classic Mini

You would like to search for DAB+ radio stations and select them on your Classic Mini?

When you use Classic Mini for the first time, the DAB scan happens automatically. All available stations are found and saved in the "**Station List**".

1. To change the DAB station, tap one of the "**Skip**" buttons to access the "**Station List**".
2. You can now scroll through the available stations by turning the "**Volume/Select**" dial.
3. Once you've found the station you wish to listen to, press the "**Select/Volume**" dial to switch to that station.

For a **new scan** simply press the "**Home**" button while being in DAB mode and select the option "**DAB Scan**".

Your radio will then delete all stored DAB stations and automatically begin scanning for all available stations.