



FAQs > Woodland Series - Outdoor Speakers/Radios > How to switch a Woodland Mini on and off?

---

## How to switch a Woodland Mini on and off?

Customer Support - 2024-10-22 - Woodland Mini

# Would you like to know how to switch your Woodland Mini on and off?

1. Pressing the "**Standby**" on/off button will boot your Woodland Mini.

When you use Woodland Mini for the first time, the unit will automatically enter a **DAB scan**.

All available stations are found and saved to the "**Station List**" without you having to do anything.

1. To switch the Woodland Mini off, keep the "**Standby**" button pressed until "**Goodbye**" is displayed, and the unit switches off.

The standby display is **only available** when connected to an **external power supply**.