

FAQs > Elan Series - DAB+ Radios > Elan One² - Quick Help

Elan One² - Quick Help

Customer Support - 2024-12-09 - Elan Series - DAB+ Radios

Our most important tips for using your portable Elan One²

Before operating the product, you should always read the <u>Elan One² Quick</u>
Start Guide.

You can find the QSG for the Elan One² in our **Download Centre.**

1. **Before we start**, let's point out the obvious.

Make sure the antenna is fully extended and all plastic covers have been removed. Connect your device to a power source via a USB power adapter (not included) or insert 4 AA batteries according to the +/- markings.

Make sure that the slider on the side is in the ON position.

1. Switching Elan One² on/off

Press the "Volume/Select" dial to switch on your Elan One².

Want to find out more?

1. Scanning and selecting DAB+ or FM stations

We have two separate articles on these topics, which you can select by clicking on the highlighted words.

1. Saving or recalling a preset

The Elan One² allows you to save your favourite stations to the quick access buttons.

More details can be found **here.**

1. Changing the source

This is kept straight forward. Pressing the "Source" button will select the source played. If you want to know more about the source options, read this article **here**.

1. Setting an alarm

The Elan One² has 2 different alarm clocks that you can set. We have created a detailed **step-by-step help article** to explain the details.

1. Pairing a Bluetooth device

When you select Bluetooth as the source, pairing mode is activated. More detailed instructions on how to find your Elan One² on the device to be paired and further information on pairing with BT can be found here.

1. Adjusting the display brightness

The brightness of the display of your Elan One² can be adjusted. **Find out how.**