



FAQs > Evoke Series - Modern Music Systems > Evoke Home > How can I scan and select DAB stations with my Evoke Home?

How can I scan and select DAB stations with my Evoke Home?

Customer Support - 2024-11-19 - Evoke Home

You would like to search for DAB+ radio stations and select them on your Evoke Home?

1. When you select DAB as a source for the first time, the Evoke Home will enter a DAB scan automatically. All available stations are found and saved in the **"Station list"**.
2. To change the DAB station, press the **"Home/select"** button to open the DAB menu,.
3. Press the **"Home/select"** button again to open the **"Station list"**.
4. Use the up/down arrow keys to move through the list of available stations.
5. Once you've found the station of your choice, press the **"Home/select"** - button to switch to that station.

With the display closed, you can also use the skip fwd/skip bwd keys to manually step through the station list.

Your first 6 presets can also be called up by pressing the direct access preset buttons under the volume control.

For a new scan simply press the **"Home/select"** button while being in DAB mode and select the option **"Scan"**.

Your radio will then delete all stored DAB stations and automatically begin scanning for all available stations.

Use the **"Prune"** function to delete stations no longer available.