



[FAQs](#) > [Help by Connection Type \(BT, Internet,...\)](#) > [Smart Speakers](#) > [DiscovR](#) > [General Questions](#) > [How do I check my speaker's battery level?](#)

How do I check my speaker's battery level?

Laura - 2021-10-19 - [General Questions](#)

To check the current battery level, press and hold the source button. The number of illuminated segments on the light ring will indicate the current level of charge remaining.