



FAQs > Classic Series - DAB+ and Music Systems > How to adjust the display brightness on the Classic H4?

How to adjust the display brightness on the Classic H4?

Customer Support - 2024-10-15 - Classic H4

Would you like to adjust the brightness of the display on your Classic H4?

1. To customize the display brightness, press the "Home" button to access the main menu.
2. Use the "Select" dial to scroll to "System Settings" and press the dial to select.
3. Scroll through the settings options until you find "Backlight" and press the dial to enter.
4. You'll see three options: "Timeout", "On Level" and "Dim Level".
5. Select the "Timeout" to define the duration until the display brightness changes from "On Level" to "Dim Level".
6. Select "On Level" to adjust the brightness when the radio is on, and "Dim Level" to adjust the brightness of the display when the radio enters dim mode. This means you can set the display to be brighter when you're actively using it, dimmer (or even off). The "Dim Level" will also affect the display when the radio is in standby.

And there you go! You can now easily adjust the display brightness of your Classic H4 radio to match your environment and preferences.