

FAQs > Woodland Series - Outdoor Speakers/Radios > How to pair a Bluetooth device with a Woodland?

How to pair a Bluetooth device with a Woodland? Customer Support - 2025-01-27 - Woodland

Would you like to pair your phone or another Bluetooth device to your Woodland?

When you switch to Bluetooth mode for the first time by selecting Bluetooth as a source, your Woodland will automatically enter pairing mode.

All you need to do is go to the Bluetooth settings on your device, find Woodland in the list, and select it to pair.

The next time you enter Bluetooth mode, Woodland will automatically try to reconnect to the last connected device.

You're now connected via Bluetooth and ready to enjoy your music wirelessly with Woodland. Use the "**Skip forward / Skip backward**" buttons to skip through tracks.

To pair a new device or if you need to re-pair/unpair a device, keep the "**Bluetooth**" button pressed until "**Pairing**" is displayed.

If no device is currently paired, Woodland will automatically enter pairing mode.