PURE

How to set up my new Classic H4i/Classic C-D6i?

Customer Support - 2025-07-29 - Classic H4i

You would like to get your new Classic H4i/Classic C-D6i setup and connected to the internet?

1. After you have connected the supplied power adapter to a power source and connected it to your Classic H4i/Classic C-D6i, the telescopic aerial has been extended, now switch on the radio by pressing the '**Standby**' button.

2. Select your preferred language by turning the '**Select**' knob.

3. Press the knob to confirm your selection.

4. Now set your time zone. First select the region, followed by a city within the region. Here, too, the selection is made using the '**Select**' control, which is confirmed by pressing the control.

5. To connect your Classic H4i/Classic C-D6i to your Wi-Fi network, confirm with '**Yes**' when you are asked if you want to '**Configure the network**'.

6. You can choose between the connection methods **Scan & Select** and **WPS** pairing.

7. With **Scan & Select**, all available networks within range of your Classic H4i/Classic C-D6i are first searched for.

8. Select your network from the list and confirm your selection with the '**Select**' button.

9. In the next step, you will be asked to enter your password.

10. Use the '**Select**' control to select the characters and confirm them one by one by pressing the '**Select**' control.

11. Once you have entered your password completely, move the cursor to '**OK**' and confirm this again with the '**Select**' control.

1. If your router has a **WPS** button, you can also set up the connection using '**WPS pairing**'.

2. After pressing the WPS button, your Classic H4i/Classic C-D6i should automatically connect to your network.

3. If the **WPS** pairing fails, try again or use the **Scan and Select** method to set up the connection

manually.

4. You can use the country and region selection to customise the list of Internet radio stations to your location.