



[FAQs](#) > [Woodland Series - Outdoor Speakers/Radios](#) > [Woodland Mini](#) > [How to switch a Woodland Mini on and off?](#)

How to switch a Woodland Mini on and off?

Customer Support - 2025-07-31 - [Woodland Mini](#)

Would you like to know how to switch your Woodland Mini on and off?

1. Pressing the "**Standby**" on/off button will boot your Woodland Mini.

When you use Woodland Mini for the first time, the unit will automatically enter a **DAB scan**.

All available stations are found and saved to the "**Station List**" without you having to do anything.

1. To switch the Woodland Mini off, keep the "**Standby**" button pressed until "**Goodbye**" is displayed, and the unit switches off.

The standby display is **only available** when connected to an **external power supply**.