



FAQs > Help by Connection Type (BT, Internet,...) > Docks and Airplay > My Contour 200i does not appear on my iPod as a detected device

---

## My Contour 200i does not appear on my iPod as a detected device

Laura - 2021-10-19 - Docks and Airplay

**Check that your Contour 200i Air is running the latest firmware to ensure you experience the best from your product!**

It's likely that your Contour device has just performed an automatic software update over the internet. Switch on your Contour and you may see the front LED flashing red for 20-30 seconds. If so, wait for the LED to turn a static white colour and you should then be able to see the Contour device listed on your Apple device to connect to.