



[FAQs](#) > [Woodland Series - Outdoor Speakers/Radios](#) > [Bloom](#) > [How do you scan for and change FM stations on a Bloom?](#)

## How do you scan for and change FM stations on a Bloom?

Customer Support - 2026-08-28 - [Bloom](#)

## Would you like to save and change FM stations on your Bloom?

When you switch to FM mode for the first time, your radio automatically scans all available FM frequencies and saves them to the presets (max. 40).

This process may take a few moments, as each station is being detected. You don't need to do anything.

To change the FM station later,

1. briefly press one of the **station list** buttons whilst in FM mode.
2. A list of saved frequencies will appear on the display.
3. Turn the **volume control** to select a station.
4. Once you have found the station you want, press the **rotary knob** to switch to that station.

If you wish to carry out another station search,

1. simply press the **Menu** button whilst in FM mode.
2. Open the '**Settings**' menu item and select the '**FM Scan**' option.
3. Confirm this by pressing the volume control.

Your radio will now delete all saved FM stations and automatically start scanning for all available stations.

In the '**Scan settings**', you can choose whether to search for '**Strong stations**' only or '**All stations**'.

