

지식 베이스 > Woodland Series - Outdoor Speakers/Radios > How to switch a Woodland Mini on and off?

How to switch a Woodland Mini on and off? Customer Support - 2024-10-22 - Woodland Mini

Would you like to know how to switch your Woodland Mini on and off?

1. Pressing the "Standby" on/off button will boot your Woodland Mini.

When you use Woodland Mini for the first time, the unit will automatically enter a **DAB** scan.

All available stations are found and saved to the "**Station List**" without you having to do anything.

 To switch the Woodland Mini off, keep the "Standby" button pressed until "Goodbye" is displayed, and the unit switches off.

The standby display is **only available** when connected to an **external power supply**.