



Baza Wiedzy > Elan Series - DAB+ Radios > How can I change the source played on my Elan One²?

How can I change the source played on my Elan One²?

Customer Support - 2024-12-09 - Elan Series - DAB+ Radios

You would like to change the source that is playing on your Elan One²?

The available sources on the Elan One² are **DAB+**, **FM**, and **Bluetooth**.

1. To choose a source for playback, simply tap on the "**Source**" button and select it by turning the "**Volume/Select**" dial.
2. Pressing the "**Source**" button repeatedly will also cycle through the available sources.
3. To confirm your selection, press the "**Volume/Select**" dial.

The source will also change to the highlighted automatically after 2 seconds, if no other button is pressed.