

How can I set an alarm on my Elan One²?

Customer Support - 2024-12-09 - Elan Series - DAB+ Radios

Would you like to set an alarm on your Elan One²?

Setting up an alarm on your Elan One² radio is very straightforward. Let's go through the steps together, using an example.

1. To activate an alarm, first press the "**Menu-Back**" button and turn the dial until you see "**System**".
2. Press the "**Volume/Select**" dial to open the system menu, scroll to "**Alarm**" and confirm by pressing the "**Volume/Select**" button.
3. Select "**Alarm 1 Setup**" and press the "**Volume/Select**" dial to confirm. This will activate the "**Alarm 1 Wizard**".
4. Set the wakeup time by turning the dial to select the hours, then press the dial to move to the minutes. Turn the dial again to set the minutes and press the dial to confirm the time.
5. Choose the duration of the alarm by turning the dial to select from the available. Press the dial to confirm.
6. Select the source. You can choose between **DAB** radio, **FM** radio, or a **Buzzer**. Turn the dial to select your preferred source and press the dial to confirm. In **DAB** and **FM** mode, the station last listened will be selected, or you can choose from one of your presets.
7. In the cycle selection you can choose from **Once**, **Weekends**, **Weekdays** and **Daily**. Confirm by pressing the dial.
8. Now set the volume at which you wish the alarm to sound. Again, confirm your setting.
9. The Alarm can be turned on/off by turning the "**Volume/Select**" dial. Press the dial to confirm.

Active alarms will be displayed by corresponding icons.

When the alarm goes off:

You can **snooze** the alarm by pressing the "**Volume/Select**" dial.

Pressing the "**Source**" button will turn it off completely.