



[Baza Wiedzy](#) > [Elan Series - DAB+ Radios](#) > [Elan Move](#) > [How to change FM stations on an Elan Move?](#)

How to change FM stations on an Elan Move?

Customer Support - 2026-03-27 - [Elan Move](#)

You would like to save and change your FM Stations on your Elan Move?

When you switch to FM mode for the first time, the system will search all available FM stations and save them to the presets.

After the search, playback begins with the first station found.

1. To access FM stations stored in the presets, short press the **"Favourite List"** button while being in FM mode. This will open the **"Preset Recall"** list.
2. Use the the **"Skip Forward"** (>|) or **"Skip Back"** (<|) button to move through the list of available stations.
3. Once you've found the station of your choice, press the **"Select"** (**Play/Select** >||) button to switch to the selected station.

Your first **2 presets** can also be recalled using the **"Favourite 1/2"** buttons.

For a new scan simply press the **"Back"** (**Home**) button, select **"FM-Scan"** and confirm by pressing the **"Select"** button.

A new scan will delete all stored FM presets.