



[Baza Wiedzy](#) > [Classic Series - DAB+ and Music Systems](#) > [Classic Aura](#) > [Jak ładować głośnik Classic Aura i sprawdzać stan baterii?](#)

## Jak ładować głośnik Classic Aura i sprawdzać stan baterii?

Customer Support - 2025-08-08 - [Classic Aura](#)

### Chcesz naładować urządzenie Classic Aura i sprawdzić stan baterii?

1. Klasyczny model Aura wymaga ładowarki USB-C o mocy od 5 W do 30 W.

Aby uzyskać optymalną prędkość ładowania i maksymalną głośność podczas ładowania, wymagana jest moc 30 W.

1. Podłącz głośnik do ładowarki USB-C.

Podczas ładowania będzie migać ikona Eco (bateria).

1. Po naładowaniu do 100% ikona Eco (bateria) przestanie migać.

Stan ładowania można również sprawdzić podczas słuchania, naciskając przycisk Eco przez 2 sekundy.

4 diody LED nad pokrętkiem głośności będą świecić, wskazując aktualny stan baterii.



Battery level		LED Behavior				Illustration
From	To	LED1	LED2	LED3	LED4	
75%	100%	high	high	high	blink	
45%	75%	high	high	blink	off	
25%	45%	high	blink	off	off	
5%	25%	high	off	off	off	
0%	5%	blink	off	off	off	


High

Low

Pulse

Blink

Off

Battery level		LED Behavior				Illustration
From	To	LED1	LED2	LED3	LED4	
95%	100%	on	on	on	on	
75%	95%	on	on	on	pulse	
45%	75%	on	on	pulse	off	
25%	45%	on	pulse	off	off	
0%	25%	pulse	off	off	off	

High

Low

Pulse

Blink

Off