



Baza Wiedzy > Woodland Series - Outdoor Speakers/Radios > How to use the Aux input on a Woodland Glow?

How to use the Aux input on a Woodland Glow?

Customer Support - 2024-10-30 - Woodland Glow

Would you like to connect a non-Bluetooth-enabled device to your Woodland Glow?

Your Woodland Glow also offers the option to connect a **non-Bluetooth** device.

1. To do so, open the rubber flap on the back of the unit, exposing the USB connectors.
2. The **AUX Input** is located above the USB-C charging port, providing a 3,5mm stereo phone socket.
3. The Woodland Glow is switched to **AUX-IN** as soon as a plug is inserted to this port.