



Baza Wiedzy > More products > Jongo > My Jongos LED is changing between amber, green and red

---

## My Jongos LED is changing between amber, green and red

Sarah Spencer - 2021-10-19 - Jongo

### **My Jongos LED is changing between amber, green and red**

This is your Jongo updating its software. Do not power off your Jongo while this is happening. This process may take up to 5 minutes to complete. When the LED is a constant green the update is complete and you can continue using your Jongo.