



[FAQs](#) > [Elan Series - DAB+ Radios](#) > [How can I change FM stations on an Elan One²?](#)

How can I change FM stations on an Elan One²?

Customer Support - 2025-02-04 - [Elan Series - DAB+ Radios](#)

You would like to save and change your FM Stations on your Elan One²?

1. To set the scan options, press the "**Menu-Back**" button to enter the menu.
 2. Enter "**Scan setting**" and choose between "**Strong stations only?**" and "**All stations**".
 3. Select "**Audio setting**" to choose if you want to listen in Mono only, in case you experience weak FM reception. (Stereo is only available with headphones)
-
1. Use the "**Stations**" navigation keys to skip through the frequencies.
 2. Holding the keys pressed for 2 seconds will enter seek mode.
 3. The Elan One² will stop at the next station received.