



FAQs > Elan Series - DAB+ Radios > How can I change FM stations on an Elan One<sup>2</sup>?

---

## How can I change FM stations on an Elan One<sup>2</sup>?

Customer Support - 2024-12-09 - Elan Series - DAB+ Radios

### **You would like to save and change your FM Stations on your Elan One<sup>2</sup>?**

1. To set the scan options, press the "**Menu-Back**" button to enter the menu.
  2. Enter "**Scan setting**" and choose between "**Strong stations only?**" and "**All stations**".
  3. Select "**Audio setting**" to choose if you want to listen in Mono only, in case you experience weak FM reception. (Stereo is only available with headphones)
- 
1. Use the "**Stations**" navigation keys to skip through the frequencies.
  2. Holding the keys pressed for 2 seconds will enter seek mode.
  3. The Elan One<sup>2</sup> will stop at the next station received.