



[FAQs](#) > [Elan Series - DAB+ Radios](#) > [How can I change the source played on my Elan One<sup>2</sup>?](#)

## How can I change the source played on my Elan One<sup>2</sup>?

Customer Support - 2025-02-04 - [Elan Series - DAB+ Radios](#)

### You would like to change the source that is playing on your Elan One<sup>2</sup>?

The available sources on the Elan One<sup>2</sup> are **DAB+**, **FM**, and **Bluetooth**.

1. To choose a source for playback, simply tap on the "**Source**" button and select it by turning the "**Volume>Select**" dial.
2. Pressing the "**Source**" button repeatedly will also cycle through the available sources.
3. To confirm your selection, press the "**Volume>Select**" dial.

The source will also change to the highlighted automatically after 2 seconds, if no other button is pressed.