How can I save/recall presets on an Elan One²?

Customer Support - 2025-02-04 - Elan Series - DAB+ Radios

You would like to save a preset or recall a preset on your Elan One²?

The Elan One² allows you to save **5** presets for **DAB+** and **FM** to the direct access preset keys.

1. To store a station to a preset, long press a preset button until "**Preset X stored**" is displayed.
2. The station listened to is now saved on the chosen preset.
3. Repeat this for all 5 presets available.

To recall a saved preset, short press the corresponding preset button.