



FAQs > Classic Series - DAB+ and Music Systems > Classic C-D6 > How to pair a Bluetooth device to a Classic C-D6?

How to pair a Bluetooth device to a Classic C-D6?

Customer Support - 2025-01-27 - Classic C-D6

Would you like to pair your phone or another Bluetooth device to your Classic C-D6?

When you switch to Bluetooth mode for the first time by selecting Bluetooth as a source, the Classic C-D6 will automatically enter pairing mode.

All you need to do is go to the Bluetooth settings on your device, find Classic C-D6 in the list, and select it to pair.

The next time you enter Bluetooth mode, Classic C-D6 will automatically try to reconnect to the last connected device.

You're now connected via Bluetooth and ready to enjoy your music wirelessly with Classic C-D6.

To pair a new device or if you need to re-pair/unpair a device, keep the "**Bluetooth/Pair**" button pressed until "**Not Connected**" is displayed.

If no device is currently paired, Classic C-D6 will automatically enter pairing mode.