



FAQs > Woodland Series - Outdoor Speakers/Radios > How to pair a Bluetooth device with the Woodland Mini?

How to pair a Bluetooth device with the Woodland Mini?

Customer Support - 2025-01-27 - Woodland Mini

Would you like to pair your phone or another Bluetooth device to your Woodland Mini?

When you switch to Bluetooth mode for the **first time** by selecting Bluetooth as a source, it will **automatically** enter pairing mode.

All you need to do is go to the Bluetooth settings on your device, find **Woodland Mini** in the list, and select it to pair.

The next time you enter Bluetooth mode, Woodland Mini will automatically try to reconnect to the last connected device.

You're now connected via Bluetooth and ready to enjoy your music wirelessly with Woodland Mini. Use the "**Skip Track - / Skip Track +**" to skip through tracks.

To pair a new device or if you need to re-pair/unpair a device, keep the "**Bluetooth**" button pressed until "**Pairing**" is displayed.

If no device is currently paired, Woodland Mini will automatically enter pairing mode.