



[FAQs](#) > [Classic Series - DAB+ and Music Systems](#) > [Classic Stereo Mini](#) > [How to scan and select DAB stations on a Classic Stereo Mini?](#)

How to scan and select DAB stations on a Classic Stereo Mini?

Customer Support - 2025-10-09 - [Classic Stereo Mini](#)

You would like to search for DAB+ radio stations and select them on your Classic Stereo Mini?

When you select DAB+ as a source for the first time, the Classic Stereo Mini will enter a DAB scan automatically.

All available stations are found and saved in the "**Station list**".

To change the DAB station,

1. Open the "**Station List**" by pressing the **Forward** or **Backward** button or the **up** or **down** keys on the remote.
2. Scroll through the "**Station List**" using the "**Select**" dial or the **up** or **down** keys on the remote.
3. Highlight the station you wish to listen to, and press "**Select**" to tune in.
4. The radio will automatically tune to the highlighted station after 2 seconds, if no button is pressed.

For a new scan simply press the "**Home**" button while being in DAB mode and select the option "**DAB Scan**".

Your radio will then delete all stored DAB stations and automatically begin scanning for all available stations.