



FAQs > Classic Series - DAB+ and Music Systems > Classic Mini > How to switch a Classic Mini on and off?

---

## How to switch a Classic Mini on and off?

Customer Support - 2025-01-27 - Classic Mini

# You would like to know the details about switching your Classic Mini on/off?

Long pressing the "**Standby**" on/off button will boot your Classic Mini.

When you use Classic Mini for the first time, the unit will automatically enter a DAB scan. All available stations are found and saved to the "**Station List**" without you having to do anything.

**Battery powered**, the Classic Mini will boot to **DAB** mode.

Connected to an **external power supply**, the Classic Mini will boot to the last source listened.

To switch the Classic Mini off, keep the "**Standby**" button pressed until the unit switches off.

The **standby display** is only available when connected to an **external power supply**.