



FAQs > More products > Elan Connect/Connect+ > How can I save presets on my Elan Connect/Connect+?

How can I save presets on my Elan Connect/Connect+?

Customer Support - 2024-09-26 - Elan Connect/Connect+

Saving a station to the quick access presets (1-2)

1. To begin with, please make sure you are tuned to the station you wish to save on a preset.
2. Once you can hear the station playing, press and hold the numbered button you wish to save the station to until 'Preset Stored' appears on screen. The station will then be saved to that preset.

To listen to one of these 2 presets, simply press (do not press and hold) one of the numbered preset buttons.

Saving a station to presets 3-20

1. Make sure you are tuned to the station you wish to save on a preset.
2. Once you can hear the station playing, press and hold the 3+ until 'Save to preset' appears at the top of the display. **If 'Recall from Preset' appears instead then you haven't held down the 3+ for long enough.**
3. Now rotate the select dial until the preset number you want to save the current station to is highlighted on screen.
4. Once it is highlighted, press the select dial in, at which point 'Preset Stored' will appear and the station will be saved.

To listen to one of these presets, simply press (do not press and hold) the 3+ button so that 'Recall from Preset' appears at the top of the display. Now turn the select dial until you come to the preset station you want to listen to. Press the select button and that station will then play.