



[FAQs](#) > [Woodland Series - Outdoor Speakers/Radios](#) > [Bloom](#) > [How do you save and recall station presets on a Bloom?](#)

How do you save and recall station presets on a Bloom?

Customer Support - 2026-08-28 - [Bloom](#)

Would you like to save a preset or recall a preset on your Bloom?

Your Bloom allows you to save up to **40 station presets**, for both **DAB** and **FM**.

You can save a radio station you're currently listening to either to one of the five **Favourites** buttons or add it to the preset list.

1. If you press one of the 5 **Favourites** buttons until the tick appears on the display, the station you're currently listening to will be saved.
2. You can quickly recall this station by briefly pressing the preset button.

1. To save a station to the preset list, press and hold the **+** button to open the favourites list.
2. Turn the volume control to select the position within the list (1-40), then press the control to confirm.
3. If you select preset positions 1-5, any previously saved stations will be overwritten.

