



[FAQs](#) > [Classic Series - DAB+ and Music Systems](#) > [Classic Active](#) > [Classic Active - Quick Help](#)

Classic Active - Quick Help

Customer Support - 2026-04-17 - [Classic Active](#)

Our most important tips on how to use your Classic Active

1. **Before operating the product**, always consult the Classic Active [User Guide](#).

You can find the User Guide for the Classic Active in our [Download Center](#).

1. **Before we start, we state the obvious.**

Make sure you have connected the passive speaker to the active speaker, attached, and fully extended the antenna and connected your unit to the proper power source.

1. **Switching Classic Active on/off**

Pressing the power switch located on the back of the active speaker to the On position will boot your Classic Active to the last source selected.

When you use Classic Active for the first time, the unit will perform a DAB scan.

1. **Scanning and selecting [DAB+](#) or [FM Stations](#)**

We have two separate articles on these topics that you can select by clicking on the highlighted links above.

1. **Saving or recalling a preset**

The Classic Active offers two methods to save presets. These can either be saved to one of the 6 quick preset buttons on the remote control or added to the preset list.

Pressing one of the quick preset buttons until "Preset stored" appears will save the station currently listened to. Short press the preset button to recall it. More details can be found [here](#).

1. **Changing the source**

This is kept straight forward. Pressing a selected source button on your remote control will access the chosen

input. If you want to know more about the source options, read [this article](#).

1. Pairing a Bluetooth device

Press the BT button and the Classic Active will enter pairing mode. More detailed instructions on how to find your Classic Active on the device you want to pair and more on pairing with BT can be found [here](#).

1. Adjusting the display brightness

The display brightness can be dimmed or even switched off completely. [Find out more](#).

1. Selecting the equalizer modes

The different modes can be reached by pressing the corresponding EQ button on the remote control. Find more [details here](#).