

FAQs > Evoke Series - Modern Music Systems > Evoke Home > How can I scan and select DAB stations wth my Evoke Home?

How can I scan and select DAB stations wth my Evoke Home? Customer Support - 2024-11-19 - Evoke Home

You would like to search for DAB+ radio stations and select them on your Evoke Home?

- 1. When you select DAB as a source for the first time, the Evoke Home will enter a DAB scan automatically. All available stations are found and saved in the "**Station list**".
- 2. To change the DAB station, press the "Home/select" button to open the DAB menu,.
- 3. Press the "Home/select" button again to open the "Station list".
- 4. Use the up/down arrow keys to move through the list of available stations.
- 5. Once you've found the station of your choice, press the "**Home/select**" button to switch to that station.

With the display closed, you can also use the skip fwd/skip bwd keys to manually step through the station list.

Your first 6 presets can also be called up by pressing the direct access preset buttons under the volume control.

For a new scan simply press the "**Home/select**" button while being in DAB mode and select the option "**Scan**".

Your radio will then delete all stored DAB stations and automatically begin scanning for all available stations.

Use the "Prune" function to delete stations no longer available.