



[FAQs](#) > [Classic Series - DAB+ and Music Systems](#) > [Classic H4i](#) > [How to change the source that is played on the Classic H4i/Classic C-D6i?](#)

How to change the source that is played on the Classic H4i/Classic C-D6i?

Customer Support - 2025-07-29 - [Classic H4i](#)

You would like to change the source that is playing on your Classic H4i/Classic C-D6i?

The available sources are **Internet radio, Podcasts, DAB+ radio, FM radio, Bluetooth, USB, CD (Classic C-D6i only)** and **Aux-In**.

To select a source for playback,

1. simply tap the '**Source**' button on your Classic H4i/Classic C-D6i to open the selection window.
2. Repeatedly press the '**Source**' button or turn the '**Select**' dial to cycle through the available sources.
3. To confirm your selection, press the '**Select**' knob.