



[FAQs](#) > [Woodland Series - Outdoor Speakers/Radios](#) > [Woodland](#) > [How do I check the status of my battery](#)  
[\[Woodland, Woodland Mini, Woodland Glow\]](#)

## How do I check the status of my battery [Woodland, Woodland Mini, Woodland Glow]

INSIDE / AQIPA - 2025-07-31 - [Woodland](#)

### Woodland

The battery indicator is located in the upper right hand corner of the display. When turning the speaker on, the display will lite up for a few seconds.

During operation, a short tap on the Power button will again illuminate the display.



### Woodland Mini

The battery indicator is located in the upper right hand corner of the display. When turning the speaker on, the display will lite up for a few seconds.

During operation, a short tap on the Power button will again illuminate the display.



## Woodland Glow

The battery status of the Woodland Glow is displayed by 4 LEDs. When turning the speaker on, the LEDs will light up for a few seconds.

During operation, a short tap on any of the buttons will recall the status.

